INSTALLATION INSTRUCTIONS

1 Clean.

2 Peel.

3 Apply.

MAGNA-LOC

magnetic lock for your shower curtain